



**Infinity Series**Athletica O&M manual

## Thank you for purchasing the Infinity Series™ dasher board system.

This manual details the recommended maintenance schedule required to ensure optimal performance of your arena system.

## Warranty

This Athletica Sport Systems product is warranted to be free of defects in materials and workmanship for a period of 1 year from the date of purchase. Please contact Athletica Sport Systems with any questions about the performance of this product.

#### **Contact Us**

#### Canada and International

554 Parkside Drive. Waterloo ON Canada N2L 5Z4 519-747-1856

#### USA

720 Innovation Drive. Shakopee MN USA 55379 763-249-7465

### **Weekly Maintenance**

- Check attachment of polyethylene facing, and caprail to aluminum framing. Tighten screws as required.
- 2. Inspect gate swing for proper clearance. Adjust as required.
- 3. Inspect gate latches for proper operation. Adjust as required. Spray lubricant on the machine gate latch and machine gate retractable flush bolts to keep the threads and finish oiled.
- 4. Inspect door/panel frame facing alignment (playing side). The smooth operation of all the gates is dependent on the level and plumb of the adjacent gate jambs and the adjacent boards.
- 5. Inspect all acrylic glass clips (if applicable), and the J-hooks in them, to ensure the hooks are tight. Tighten as needed to prevent glass clips from dislodging.
- 6. Inspect Suction cups are all attached to the glass.

### **Monthly Maintenance**

- 1. Check torque of floor anchors. Tighten as required.
- 2. Visually inspect plumb of dasher boards. Re-plumb as required.
- 3. Visually inspect aluminum framing for deformation or cracks. Repair or replace as required.
- 4. Inspect panel joints (playing side) for facing alignment. Re-adjust/tighten as required.
- 5. Check torque of panel connection bolts. Re-tighten as required.
- Do regular cleaning of polyethylene and glass facing for esthetics. Use mild detergent and water. Wipe dry. Never use a solvent or abrasive cleanser.
- 7. Inspect any steel hardware for start of corrosion. Clean off rust and spray galvanize as required. Wipe the tie rods with spray lubricant to protect the nickel plating.

- 8. Lubricate gate hinges. Use a quality spray lubricant on the gate hinges and all the moving parts on the gate locking hardware.
- 9. Lubricate adjustable caster. Use quality grease on the grease fitting on the machine gate wheels, with a grease gun.
- 10. Check torque of hardware fasteners. Tighten as required.
- 11. Inspect threshold covers for wear. Replace as required.
- 12. Inspect threshold covers for proper attachment Tighten/fasten as required.

To schedule a maintenance or repair by authorized service personnel, call Athletica Sport Systems Inc., toll-free: 1.877.778.5911 or contact us via email at info@athletica.com.

# **Infinity** Series<sup>™</sup>



554 Parkside Drive, Waterloo, Ontario, Canada N2L 5Z4 **TEL** 519-747-1856 720 Innovation Drive, Shakopee, Minnesota, USA 55379 **TEL** 763-249-7465

athletica.com







